


Pressing on Tool


Engine (cont'd)

Valve Spring Lifter

with cylinder head removed



for removing and installing valves,



Order Number 223- 112 620(A) 112 630(B)

Drift

for driving in the radial sealing ring for the crankshaft into the timing case cover



Order Number 224 111 850

Centering Bushing with Sliding Sleeve

for centering timing case cover and driving in radia. sealing ring for camshaft sealing into cover



Order Number 225 111 820

Extractor

for pulling off the flywheel



Order Number 226 112 810